

Finding Items Going to a Destination

Using the Man OverBoard (MOB) Feature

GPSMAP® 376C Quick Reference Guide




The GPS antenna must be in the upright position to receive satellite signals.

To find a waypoint or other item from your current location:

- 1. From any page, press **FIND**.
- 2. Highlight a category from the list, and press **ENTER**.
- 3. Highlight an item in the results list, and press **ENTER**.





avaid • From Current Location

Find Menu

IN/OUT—press to zoom in or zoom out on the Map Page.



PAGE/MODE—press to cycle through the main pages in sequence and return the display from a submenu page. Press and hold to switch between Marine Mode and Automotive Mode.



QUIT—press to cycle through the main pages in reverse sequence, revert to the previous value in a data entry field, or cancel a function.



ENTER/MARK—press to select a highlighted option, initiate entry, and then confirm. Press and hold to mark a waypoint.



MENU/Wx—press to view Options Menu for the current page. Press twice to open the Main Menu. Press and hold to turn the Map Page weather off and on.



NAV/MOB—press to open the Navigation Menu window. In Marine Mode, press and hold to activate the MOB function. In Automotive Mode, press and hold to show the Next Turn Page and have the voice prompt announce the next turn.



FIND—press to show the Find Menu.



POWER—press and hold to turn the unit on or off. Press and release to adjust the backlighting and external speaker volume.



ROCKER—press up, down, left, or right to select menu options, enter data, or move the pointer on the Map Page.

To find an item from another location using the Find menu:

- 1. From any page, press **FIND**.
- 2. Press MENU. Highlight Near Other, and press ENTER.
- 3. Select a reference point on the map, and press **ENTER**. The list shows items nearest to the new map location.

To find an item from another location on the Map Page:

- . From the Map Page, use the **ROCKER** to pan to the location you want, and press **FIND**.
- 2. Highlight a category from the list, and press **ENTER**.
- 3. Highlight an item in the results list, and press **ENTER**.



Find From Map Pointer

Search Results

To Go To a highlighted map item:

- 1. Use the **ROCKER** to highlight the item you want to navigate to on the Map Page.
- Press NAV/MOB, and then press ENTER.
- 3. Follow the magenta route created on the Map Page. You can also use the Compass Page to help you navigate to the point.





Navigation shown on the Map Page (Marine Mode)

To activate a Go To from the Find Menu:

- 1. Press the **NAV/MOB** key.
- 2. Use the **ROCKER** to highlight **Go To Point**, and press **ENTER**.
- From the Find menu, highlight Waypoints, and press ENTER.
- Select a waypoint from the list, and press ENTER to open the Waypoint Review Page.
- 5. With the **Go To** button highlighted, press **ENTER** to begin navigation.

Use the MOB function to simultaneously mark and set a course to a location for quick response to emergency situations.

To start the MOB function:

- 1. Press and hold the **NAV/MOB** key, or press the **NAV/MOB** key twice.
- 2. Press **ENTER** to confirm and begin navigating to the MOB location.



MOB Confirmation Window

When a MOB is initiated, a MOB waypoint is created, and the unit begins to navigate to that point. Use any of the navigation pages to guide you back to the MOB point. The MOB waypoint is stored in the Waypoint list and can be deleted like any other waypoint.

Creating a Route

Adding Via Points to Your Route

Marking a Waypoint **Using XM WX Weather and XM Radio**

To create a route using the Find Menu:

- 1. Press **MENU** twice to open the Main Menu
- 2. Highlight the Route tab.
- 3. Highlight the first available blank route slot, and press **ENTER**.
- 4. Press ENTER again to find items to add to the route.





Cape Henry-Anchorage be Course Distance 4 ETA Anchorage 034% 114h

Adding points to the route

To create a route graphically:

- 1. From the **Route** tab, highlight the first blank slot, and press **ENTER**.
- 2. On the Route Review Page, press MENU to open the options menu.
- 3. Highlight Edit on Map, and press ENTER.
- 4. Highlight a map item, and press **ENTER**.
- 5. When finished press **QUIT** twice to return to the Route Review Page.



Route Review Page Options Menu



Creating a new route on the map

To add Via Points to your route in Automotive Mode:

- While navigating your route, press NAV/MOB.
- 2. Use the **ROCKER** to select **Edit Vias**, and press **ENTER**. The Add/Edit Vias Page appears.
- 3. With the **Add Via Point** button highlighted, press **ENTER**.



Oak Park Mall Add Via Point Use Map Use Find Menu

Navigate Options

Add Via Point

- Highlight either **Use Map** or **Use Find Menu**, and press **ENTER**.
- 5. If you selected **Use Map**, use the **ROCKER** to select an item on the map, and press **ENTER**.
 - If you selected **Use Find Menu**, select an item from the Find Menu. Remember you can press **MENU** while the Find Menu is open to find an item near another location, such as the destination.
- 6. Highlight **Done**, and press **ENTER** to apply the new Via Points to the route.

Add/Edit Vias Page



New Via Point added before the destination

To mark your current location:

- 1. Press and hold ENTER/MARK until the New Waypoint Page appears.
- 2. To accept the waypoint with the defaul name and symbol, highlight **OK**, and press ENTER/MARK.
- 3. To change the any information on **New Waypoint Page** the New Waypoint Page, highlight the appropriate field, and press ENTER/MARK. After entering and confirming your changes, highlight **OK**, and press **ENTER/MARK**.

0007

25-0CT-06 14:06

Delete Show Map OK

To create a new waypoint using the Map Page:

- Press **PAGE** until the Map Page appears.
- 2. Move the pointer to a map location or map feature.
- 3. Press and guickly release **ENTER/MARK** to capture the pointer location.
 - If you have highlighted a map feature, an information page appears after you press ENTER/MARK. Use the ROCKER to highlight Save and press ENTER/MARK to save the item as a waypoint. The New Map Waypoint Page appears.
- To accept the waypoint with the default name and symbol, highlight OK, and press ENTER/MARK.

To change any information on the New Map Waypoint Page, highlight the appropriate field and press ENTER/MARK. After entering and confirming your changes, highlight **OK**, and press **ENTER/MARK**.

To turn off XM WX Weather on the Map Page:

- Press **PAGE/MODE** until the Map Page appears.
- 2. Press and hold MENU/Wx. On the Map Page, XM WX Weather is turned off.
- Press and hold MENU/Wx to turn XM WX Weather on again.



XM WX Weather

To select an XM Radio channel:

- Press **MENU** twice to open the Main Menu
- 2. Use the **ROCKER** to highlight the **XM** tab.
- Press right on the **ROCKER** to highlight the **Audio** sub tab.
- 4. Press up or down on the ROCKER to scroll through the list of channels, highlight the channel you want, and then press ENTER.





Selecting an XM Radio channel

Adding a channel to Favorites

To add a channel to the Favorites category:

- 1. Use the **ROCKER** to select a channel, or use the **IN** and **OUT** keys to select a category, and then highlight a channel.
- 2. Press MENU, highlight Add To Favorites, and press ENTER.
- 3. With **Yes** highlighted, press **ENTER** again to add the channel to the Favorites category.
- 4. To view Favorites, use the IN and OUT keys to change the category to Favorites.

^{*}XM® Radio and XM WX® Weather Data each require a monthly subscription, which is sold separately. All programming fees and weather data are subject to change.